



P.O. BOX 87, 220 Carpenter St., Greenport, NY 11944
Ph: 631 477-2400, Fax: 631 477-1095

INSTALLATION OF STIDD LOGO

Remove four screws holding backrest cushion to backrest frame. You will either install the logo into the backrest frame or the padded backrest shell!

1. Make sure two holes are clear and push studs through the back.



2. Tightly hold logo or clamp with small C-Clamp taking care not to damage back.
3. Push crowned "push-nuts" onto studs. Use of a small nut (or any small tube) lowered over the stud will help press the push-nut into place

