



## **12VDC POWER PEDESTALS FOR SERIES 1200**

Supplement to installation, operation, & maintenance manual

Part # 500-9001 Power Pedestals For 1200 series seats

### **Installation instructions:**

**Two separate power supplies must be run.**

**Electrical Requirements for each pedestal:**

**12vdc/ 20 amp maximum load each.**

**Fuse each with 25 Amp circuit breaker.**

**Connect 12 VDC power supply to terminal strip (supplied)  
under pedestal base.**

**Red wire is positive (+), Black wire is ground (-).**

**For further technical information regarding installation please contact:**

**Chris Marotta 631-477-2400 Ext. 129**



## **24VDC POWER PEDESTAL FOR SERIES 1200**

Supplement to installation, operation, & maintenance manual

Part # 500-9001 Power Pedestals For 1200 series seats

### **Installation instructions:**

**Two separate power supplies must be run.**

**Electrical Requirements for each pedestal:**

**24vdc/ 10 amp maximum load each.**

**Fuse each with 15 Amp circuit breaker.**

**Connect 24 VDC power supply to terminal strip (supplied)  
under pedestal base.**

**Red wire is positive (+), Black wire is ground (-).**

**For further technical information regarding installation please contact:**

**Chris Marotta 631-477-2400 Ext. 129**